



LIFEGUARD CHAIRS, STATION & OBSERVATION PLATFORMS

Maintenance & Care Stainless-Steel Equipment

LIFEGUARD CHAIRS

Features and Benefits with Options – Refer to Drawing(s)

Paddock manufactures several types of stainless-steel movable lifeguard chairs to provide the perfect view for any pool deck, indoor or outdoor.

Paddock's movable Lifeguard chairs are fabricated from type 304L or 316L stainless steel frame with a molded fiberglass swivel seat six feet (6 FT. standard, 5 FT & 4 FT available) above the pool deck.

The rigid 19 inches wide slip-resistant high-density polyethylene (HDPE) platform is reached via a 15-degree sloping ladder treads are stainless-steel, 19 inches by 4 inches with slip-resistant surface.

Rubber bumpers are on bottom of chair to protect the deck surface and keep in place.

Wheels secured to back of the frame for easy positioning at various poolside locations.

An umbrella socket on one side behind the seat is an integral part of the chair frame.

There is a "J" hook on one upright for the Life Ring & Rope.

Exposed surfaces shall be polished to a Paddock buff finish (standard).

Powder Coating is available by request.

Paddock's Lifeguard chair sizes:

6 FT (72" seat height) - standard

5 FT (60" seat height)

4 FT (48" seat height)

Safety & Hazard

Lifeguard chairs are intended for the use of one person at a time; they are not designed for handstands or other gymnastic stunts, and they should not be used for this purpose. Ladder treads should be inspected regularly. If a tread becomes loose or damaged, the lifeguard chair should be taken out of service until repairs are made. There is a Warning Label on all chairs if they start to peel or come off, they must be replaced.

For questions concerning the usage of our equipment, please contact Paddock Pool Equipment Co., customer service.

Observation - Refer to Drawing(s)

Features and Benefits with Options

Paddock manufactures a stainless-steel movable platform to provide maximum visibility across a wide area and extra space for uninterrupted lifeguard changes, the perfect view for any pool deck, indoor or outdoor.

Paddock's movable platform is designed for strength and stability, the 36" x 78" x 74" size chair. It is fabricated from type 304L or 316L stainless steel frame with a molded fiberglass swivel seat assembly 5 feet above the pool deck with slip-resistant platform.

The Observation platform is (36" x 60") wide slip-resistant high-density polyethylene (HDPE) is reached via the chair treads spaced 19" apart with a 15-degree sloping ladder. The ladder treads are stainless-steel, 19 inches long by 4 inches wide with slip-resistant surface.

Curved handrails permit safe access and descent by providing security for lifeguards standing on the platform. A fixed cross brace is placed directly behind the seat for added protection. The area directly in front of the seat is open to enhance the lifeguard's vision and permit quick rescue.

Rubber bumpers are on bottom of chair to protect the deck surface and keep in place. Rear wheels are secured to back of the frame for easy positioning at various poolside locations.

An umbrella socket on one side behind the seat is an integral part of the chair frame.

There is a "J" hook on one upright for the Life Ring & Rope.

Exposed surfaces shall be polished to a Paddock buff finish (standard).

Powder Coating is available by request.

Paddock's Lifeguard chair sizes:

Observation Platform - 5 FT (60" seat height) – Platform is reached from either side from ground level to platform via ladders.

Safety & Hazard

Observation Platform are intended for the use of one person at a time; they are not designed for handstands or other gymnastic stunts, and they should not be used for this purpose. Ladder treads should be inspected regularly. If a tread becomes loose or damaged, the observation chair should be taken out of service until repairs are made. There is a Warning Label on all chairs if they start to peel or come off, they must be replaced.

For questions concerning the usage of our equipment, please contact Paddock Pool Equipment Co., customer service.

Lifeguard Stations - Refer to Drawing(s)

Features and Benefits with Options

Paddock manufactures several types of stainless-steel movable station chairs to provide the perfect view for any pool deck, indoor or outdoor, provided and designed for added safety and stability with the platforms allowing extra space for lifeguard changes.

Paddock's movable station chairs are fabricated from type 304L or 316L welded stainless steel frame with a molded fiberglass swivel seat with slip-resistant platform.

The Lifeguard Stations are (48" x 48") wide slip-resistant high-density polyethylene (HDPE) is reached via a rear-mounted integral ladder. The rigid 19 inches wide platform is reached via a 15-degree sloping ladder treads are stainless-steel, 19 inches by 4 inches with slip-resistant surface.

Rubber bumpers are on bottom of chair to protect the deck surface and keep in place.

Wheels secured to back of the frame for easy positioning at various poolside locations.

An umbrella socket on one side behind the seat is an integral part of the chair frame.

There is a "J" hook on one upright for the Life Ring & Rope.

Exposed surfaces shall be polished to a Paddock buff finish (standard).

Powder Coating is available by request.

Paddock's Lifeguard Station sizes:

4 1/2 FT (54" seat height) – Platform is reached via a rear-mounted with two steps from ground level to platform.

2 1/2 FT (30" seat height) – The shortest chair with excellent visibility in recreational or instructional settings, in the zero-depth or shallow areas. Platform is only one step from ground level to platform to enter/exit from front or rear.

Safety & Hazard

Lifeguard stations are intended for the use of one person at a time; they are not designed for handstands or other gymnastic stunts, and they should not be used for this purpose. Ladder treads should be inspected regularly. If a tread becomes loose or damaged, the lifeguard station should be taken out of service until repairs are made. There is a Warning Label on all chairs if they start to peel or come off, they must be replaced.

For questions concerning the usage of our equipment, please contact Paddock Pool Equipment Co., customer service.